


8800 Series Software Installation

NOTE: When loading Software into the 8800, the Calibration Values are not affected.

Follow these instructions to install System Software in the Unit:

1. After downloading the 8800 system software zip file from the website, extract the downloaded file to the root (top-level) directory of your USB flash drive. This process varies depending on your operating system. **If unsure how to extract the file, consult your IT department.**
2. Verify that the extracted files are in the right location, as shown below.
[Drive letter]:\Aeroflex\Common



3. On the 8800, navigate to Utilities>Software>System.



8800 Series Software Installation

4. Select the Network tab and set the Network Mode to DHCP as shown below.



5. Insert the USB flash drive into one of the USB ports on the test set. Navigate to Utilities>Software>Update as shown below.




8800 Series Software Installation

- From the System Update screen, press Copy From USB.



- After the status field shows "Files are ready to install", press Install Software. At this point it is safe to remove the USB flash drive.



- The screen will go black for a moment, then a progress bar will appear showing the installation progress. After the update is complete, you will be prompted to cycle power on the unit. The update is complete.